

TBX50

Two Box Trailer

Owner's Manual



General Information

1

Introduction

This chapter will provide you with important general information regarding the safe operation of your unit and necessary warranty information.

This chapter is further broken down into the following sections:

Introduction	1-1
Important Notices	1-2
Safety Warnings	1-3
Cautions	1-3
Safety Operating Procedures	1-4
Manufacturer's Warranty	1-6
Warranty Procedure	1-8
Warranty Report	1-9

Important Notices

We have attempted to cover as much information as possible in this manual. However, this information does not cover all the unique variations that a TBX-Two Box Trailer may present. Note that illustrations are typical but may not reflect all the variations of assembly. Also all data provided is based on information that was current at time of release. However, this information is **subject to change without notice**.

Safety Warnings

This section contains important safety warnings and cautions. Please read this section carefully to avoid serious injury or death. All safety precautions described in this section should be completely and thoroughly understood and used by all personnel using the equipment.

Warning: Carelessness in the operation of this equipment can result in serious injury or death. This equipment should only be operated by qualified personnel.

Cautions

To prevent possible injury or death:

- **Do Not** travel with the hoist in the raised position.
- **Do Not** go under a raised hoist unit without first propping the hoist unit to prevent accidental lowering.

Warning: Unload the unit before performing maintenance and service on it.

- **Do Not** leave the unit raised or partially raised while unattended or during performance of maintenance or service under unit. Unless you have propped the unit to prevent it from accidentally lowering.
- **Do Not** attempt to raise a loaded unit when vehicle is on unlevelled ground.
- **Do Not** stand or move through the area where the unit is operating.

Safety Operating Procedures

G&H Manufacturing, Ltd. designs and constructs its equipment with “state-of-the-art” precision incorporating every possible safety provision into the unit at the time of manufacture. However, no equipment can be designed for completely safe operation. Unless the equipment is installed and operated as intended by the Manufacturer and protected from tampering or misuse by unauthorized personnel.

Such persons, untrained operators and stray personnel, who may be tempted to play with the controls or equipment, are considered unauthorized personnel. Therefore, it is very important that the owner(s) and/or operator(s) take the following precautions regarding risks from mechanical or hydraulic components:

- **All malfunctions or indications of improper operation** should be reported to the owner(s) to allow for immediate inspection and repair.
- **No adjustments, modifications, alterations, or repairs should be made** to the equipment by anyone other than qualified personnel.
- **All individuals authorized to operate the equipment should be trained** in the proper use of the controls. All potential danger points should be specifically pointed out to the operator(s). The owner(s) of the equipment should keep in mind that newly hired employees might acquire bad working habits or misinformation from older employees. All training activities should be delegated only to responsible individuals.

Note: It is suggested that a periodic review of safety measures be conducted for all operators, particularly where equipment is leased to and operated by customers unfamiliar with refuse equipment.

- **No untrained personnel should be allowed to operate the equipment** at any time. No one other than the authorized operator(s) should be allowed to have the keys to this equipment.
- **No trash, oil, or other slippery materials** should be allowed to clutter the work area to prevent falls.

Note: The presence of hydraulic oil beneath the equipment may indicate a leak in need of repair.

- **All indications of a need for repair should be carefully monitored.** These indications include but are not limited to blown fuses, electrical equipment sparking, electrical shocks from touching the equipment, bulging or deformed structural members, cracked welds or steel members, excessive oil leaks, or abnormal appearance or performance of the equipment.

Warning: To prevent possible injury or death, the hoist must be in the full down position for over the road travel.

Warning: The manufacturer is responsible for safety in design and construction, but the owner(s) and operator(s) are responsible for safe operation of the equipment.

Warning: G&H Manufacturing makes no warranties regarding the safety of the equipment unless these safety instructions are observed by the owner(s) and operator(s) at all times.

Manufacturer's Warranty

G&H Manufacturing, Ltd., referred to herein as the Manufacturer, warrants each new product of its own manufacture to be free from defects in material and workmanship, under normal use and service, to the original purchaser only, for a period of twelve (12) months, subject to the conditions outlined below. Our obligation under this warranty is limited to repair or replacement with a genuine G&H part, any part of the product of our manufacture which **is returned to us within thirty (30) days after discovery of the defect**, properly identified and transportation charges prepaid, and not more than twelve (12) months after purchase by the original purchaser, provided that, in our judgment, the part is defective.

The Manufacturer will furnish, without charge, **FOB** our plant a genuine G&H part. To replace any part of a product of its manufacture that proves to be defective in normal use and service during this period.

The Manufacturer's warranty or obligation in connection with the sale of this equipment:

1. Shall be expressly limited to the repair or replacement of the defective parts, as stated above and covers only those labor charges specifically authorized by the Manufacturer. All other damages and claims, statutory or otherwise, being hereby expressly waived by the purchaser, this includes but is not limited to any towing cost and damage incurred from equipment down time.
2. Shall not apply to any failure or damage incurred through neglect, lack of maintenance, misuse, accident, improper installation, redesigning of assemblies, or through any other cause beyond the control of the Manufacturer.
3. Shall not apply to any major component such as cylinders, pumps, valves, etc., which have been disassembled in any way, or if any parts are left uncovered.
4. Shall not apply if the equipment has been operated beyond the factory recommended maximum capacity.
5. Does not cover products of other manufacturers beyond such warranty as is made by such manufacture.
6. Service parts sold by G&H Manufacturing, Ltd (hoses, cables, filters, etc.) shall have a ninety (90) day warranty for replacement only, provided that factory inspection reveals a material or workmanship defect. Any labor required to replace or repair the part shall be the responsibility of the owner.

7. All perspective warranty parts must be returned to a location selected by G&H no more than thirty (30) days after receiving the replacement part or the warranty can be voided.
8. No claim under this warranty shall be valid, unless such claim is submitted within twelve (12) months after date of sale or within thirty (30) days after the discovery of the defect, which is the basis for such claim, whichever event shall occur first.
9. Equally important to you as any specific time warranty, is the fact that the Manufacturer's reputation for quality and dependability is tradition as old as the company itself. It has always been a basic company policy to insure complete customer satisfaction. This is your assurance that you can expect prompt and courteous service on your equipment from the entire factory organization.
10. There are no warranties, expressed or implied, which extend beyond the warranty set forth in this Owner's Manual, and any other warranties, expressed or implied, are hereby disclaimed by the Manufacturer.

Warranty Procedure

To best serve our customers needs the warranty department will use the following procedure to handle all warranty claims.

1. Customer notifies G&H home office at (800) 654-5291 of warranty need. The replacement parts will be shipped out that day (overnight shipping is available upon request and depending on parts availability).
2. Warranty report (Found on page 1-9 of this manual or call (800) 654-5291 to have a copy faxed to you) must be filled out completely and mailed or faxed to the contact information below.

G&H Manufacturing Ltd.
1015 Commercial Blvd. S.
Arlington TX. 76001
Fax: (817) 468-3272

3. Customer must issue a purchase order for the new part(s) and return the defective part(s) within two weeks of receiving the replacement part(s) or, the warranty request will be voided. To return a defective part(s), the customer needs to obtain a return number from the parts salesperson and send damaged or defective part(s) to the above address for G&H manufacturing.
4. G&H will return the part(s) to the original vendor for inspection or certification upon receipt of the damaged or defective part(s). If the warranty is valid G&H will issue credit to the customer for the warranty claim amount.

Warranty Report

Customer _____ Date _____

Address _____ Rep. _____

City _____ State _____ Zip _____ Phone _____

Product _____ Model _____ S/N _____

Date Shipped _____ Date Put Into Service _____

Original Sales Order No. _____ Original Work Order No. _____

Problem

Solution

Action Taken

Warranty Approved ____ Yes ____ No Repair Price \$ _____

Reported

By _____

Approved

By _____

Operating a TBX-Two Box Trailer

Introduction

This chapter contains information, instructions, and diagrams that will help you operate your TBX-Two Box Trailer. Please note that the first two sections must be read and fully understood before operating your TBX-Two Box Trailer.

G&H Manufacturing has designed this chapter for use in the cab by the operator. We suggest that you make a copy of this chapter, put it in a plastic page protector, and place it in the cab of the truck for reference.

Consider how airline pilots fly planes. No matter how often they have performed a task, they use a written procedure to increase safety. **You can never be too careful.**

This chapter is further broken down into the following sections:

Introduction	2-1
Lowering and Raising the Landing Gear	2-2
Hooking and Unhooking the TBX-Two Box Trailer	2-3
Operating the Controls.....	2-4
Loading Containers Onto the TBX-Two Box Trailer.....	2-5
Dumping the Container From the TBX-Two Box Trailer	2-8
Unloading Containers From the TBX-Two Box Trailer.....	2-9

Lowering and Raising the Landing Gear

Use the landing gear crank on the front driver's side to raise or lower the trailer. The crank on the landing gear is a two speed crank.

To Choose the Landing Gear Speed:

- Pull the crank out to operate faster (lighter loads).
- Push the crank in to operate slower (heavier loads).

To Raise and Lower the Landing Gear:

- Turn clockwise to raise the trailer and lower the landing gear.
- Turn counterclockwise to lower the trailer and raise the landing gear.

Hooking and Unhooking the TBX-Two Box Trailer

Caution: Always test the lights and breaks before transporting the trailer.

To Hook the TBX-Two Box Trailer and a Truck:

1. Crank the landing gear on the trailer to the appropriate height for the truck.
2. Back the truck in front of the trailer aligning the truck with the trailer.
3. Back the truck into the trailer triggering the automatic latch on the fifth wheel.
4. Pull the truck forward to make sure the automatic latch has locked.
5. Raise the landing gear completely.
6. Hook up the hydraulic lines.
7. Hook the red air supply line from the truck into the glad hand on the trailer.
8. Hook the blue control air line from the truck into the glad hand on the trailer.
9. Plug the electrical plug from the truck into the corresponding socket on the trailer.

To Unhook the TBX-Two Box Trailer From a Truck:

1. Unhook the hydraulic lines.
2. Unhook both glad hands.
3. Unplug the electrical plug from the socket.
4. Lower the landing gear.
5. Pull the Fifth Wheel Release.
6. Pull the truck away from the trailer.

Operating the Controls

The first two controls are used for operating the hoist and hoist cable. The third control is used for the transfer cable.

To Use the Cable and Hoist:

1. Locate the controls half way down on the driver's side of the trailer.
2. Use the left control to raise or lower the hoist:
 - Pull the handle to raise the hoist.
 - Push the handle to lower the hoist.

Use the middle control to let the cable in or out:

- Pull the handle to bring the cable in.
- Push the handle to let the cable out.

Use the right control to move the transfer cable back and forth on the trailer:

- Pull the handle to move the transfer cable to the front
- Push the handle to move the transfer cable to the rear.

To Let Air In and Out of the Axle Air Bags:

Warning: If you do not release the air from the air bags before loading or unloading the trailer you risk damaging the air bags.

In order to load or unload containers from the trailer you will need to let the air out of the axle air bags. The air bag control button is the button located on the trailer side of the control valve assembly. In order to operate the axle air bags:

- Turn the button to the right to let air out of the axle air bags.
- Turn the button to the left to push air back into the axle air bags.

To Use the Trailer Park Brake Release Button:

Note: To operate the trailer park brake release button the truck must be in neutral with the P.T.O. engaged and the truck brakes not set.

Note: The trailer park brake release button is a dead man's switch and will only release the trailer's parking brake when pushed in and held.

The trailer park brake release button is located on the trailer valve control directly behind the hoist and cable controls. To move the trailer and truck forward from outside the cab press and hold the trailer park brake release button. The trailer's parking brakes will release and the weight of the truck will pull the trailer forward. To stop moving the trailer and truck forward release the park brake release button.

Loading Containers Onto the TBX-Two Box Trailer

- Warning:** The P.T.O. must be shifted out before driving the truck. Your failure to shift out the P.T.O. before driving the truck can result in injury or death.
- Warning:** When the transfer cable is not connected to a box be careful that the ring does not become entangled in the trailer components or cross members while moving the cable.
- Warning:** When raising or lowering the hoist, it is the operator's responsibility to make sure the transfer cable does not have slack and interfere with the operation of the hoist.
- Warning:** Only pull or back the trailer or truck over level ground. Do not pull or back the trailer or truck over ground that has been unlevelled by dumping the truck or trailer.
- Warning:** Never operate the hoist while anyone is around the work area.
- Warning:** When lowering the hoist make sure the P.T.O. is in gear to prevent creating air in the system and overflowing the oil tank.
- Caution:** Read and understand the instructions for shifting the P.T.O. for your brand of truck and using the control valves for the TBX-Two Box Trailer before operating the trailer.
- Caution:** Do not load or unload the trailer with the axle air bags inflated.

To Load the First Container:

1. Back the trailer up to the container.
2. Set the trailer park brake from inside the cab leaving the truck in neutral.
3. Engage the P.T.O.
4. Release the air from the axle air bags.
5. Let the hoist cable out.
6. Raise the trailer hoist until the rear roller is touching the ground.
7. Hook the rectangular end of the hoist cable onto the container hook.
8. Pull the hoist cable in while releasing the trailer park brakes, this will allow the trailer to be pulled under the container as the container slides up the hoist.
9. Set the trailer park brake when the container guides are past the hinge point on the hoist.
10. Continue to pull the hoist cable in while lowering the trailer hoist gradually until the hoist is level.
11. Pull the container forward as far as possible.

To Move the First Container to the Front of the Trailer:

1. Let the hoist cable out enough to unhook from the container hook.
2. Pull in the hoist cable.
3. Place the rectangular cable end in front of the vertical sheave where it will not interfere with the operation of the transfer cable.
4. Attach the transfer cable ring to the container hook.
5. Engage the transfer cable, moving the container to the front of the trailer.
6. Pull the box completely to the front stops.
7. Attach the four ratchet tie downs to the container guides.
8. Tighten the ratchet tie downs with the ratchet, located by the valve controls, securely latching the container guide before transport.
9. Inflate the axle air bags.
10. Disengage the P.T.O.
11. Release the trailer park brake from inside the cab.

To Load the Second Container:

3. Back the trailer up to the container.
4. Set the trailer park brake from inside the truck cab leaving the truck in neutral.
5. Engage the P.T.O.
6. Attach the drop-in stops to the hoist.
7. Dump the air from the axle air bags.
8. Let the cable out.
9. Raise the trailer hoist until the rear roller is touching the ground.
10. Hook the rectangular end of the cable to the container hook.
11. Pull the cable in while releasing the trailer park brakes, this will allow the trailer to be pulled under the container as the container slides up the hoist.
12. Set the trailer park brake when the container guides are past the hinge point on the hoist.
13. Continue to pull the cable in while lowering the trailer hoist gradually until the hoist is level.
14. Pull the container completely to the drop-in stops.
15. Attach the four ratchet tie downs to the container guides.
16. Tighten the ratchet tie downs with the ratchet, located by the valve controls, securely latching the container guide before transport.

17. Inflate the axle air bags.
18. Disengage the P.T.O.
19. Release the trailer park brake from inside the cab.

Dumping the Container From the TBX-Two Box Trailer

- Warning:** The P.T.O. must be shifted out before driving the truck. Your failure to shift out the P.T.O. before driving the truck can result in injury or death.
- Warning:** When the transfer cable is not connected to a box be careful that the ring does not become entangled in the trailer components or cross members while moving the cable.
- Warning:** When raising or lowering the hoist, it is the operators responsibility to make sure the transfer cable does not have slack and interfere with the operation of the hoist.
- Warning:** Only pull or back the trailer or truck over level ground. Do not pull or back the trailer or truck over ground that has been unlevelled by dumping the truck or trailer.
- Warning:** Never operate the hoist while anyone is around the work area.
- Warning:** When lowering the hoist make sure the P.T.O. is in gear to prevent creating air in the system and overflowing the oil tank.
- Caution:** Read and understand the instructions for shifting the P.T.O. for your brand of truck and using the control valves for the TBX-Two Box Trailer before operating the trailer.

To Dump a Container:

20. Back the truck up to the dumpsite.

21. Set the trailer park brakes from inside the cab, leaving the truck in neutral.

Engage the P.T.O.

Open the end gate on the container.

Raise the hoist.

Press the trailer park brake release button to move the truck and trailer forward and dump the contents of the container.

Lower the Hoist.

Close the end gate on the container.

Release the trailer park brake from inside the cab.

Disengage the P.T.O.

Unloading Containers From the TBX-Two Box Trailer

- Warning:** The P.T.O. must be shifted out before driving the truck. Your failure to shift out the P.T.O. before driving the truck can result in injury or death.
- Warning:** When the transfer cable is not connected to a box be careful that the ring does not become entangled in the trailer components or cross members while moving the cable.
- Warning:** When raising or lowering the hoist, it is the operators responsibility to make sure the transfer cable does not have slack and interfere with the operation of the hoist.
- Warning:** Only pull or back the trailer or truck over level ground. Do not pull or back the trailer or truck over ground that has been unlevelled by dumping the truck or trailer.
- Warning:** Never operate the hoist while anyone is around the work area.
- Warning:** When lowering the hoist make sure the P.T.O. is in gear to prevent creating air in the system and overflowing the oil tank.
- Caution:** Read and understand the instructions for shifting the P.T.O. for your brand of truck and using the control valves for the TBX-Two Box Trailer before operating the trailer.

To Unload the Second Container:

1. Back the truck up to the offload site.
2. Engage the P.T.O.
3. Remove the four ratchet tie downs from the container guides.
4. Slowly raise the hoist while letting the cable out until the back of the container is touching the ground.
5. Let the rest of the cable out.
6. Pull the truck forward slowly, letting the rest of the container slide to the ground.
7. Unhook the rectangular end from the container hook.
8. Lower the hoist.
9. Hook the cable onto the trailer's holding hook.
10. Pull the cable in.
11. Disengage the P.T.O.

To Move the First Container to the Rear:

1. Remove any drop-in stops that are on the hoist.
2. Remove the four ratchet tie downs from the container guides.
3. Engage the transfer cable, moving the container to the back of the trailer.
4. Pull the box completely onto the hoist.
5. Unhook the transfer cable from the container hook.
6. Let the hoist cable out enough to attach the rectangular end.
7. Hook the rectangular end to the container hook.
8. Remove any slack from the hoist cable.

To Unload the First Container:

1. Back the truck up to the off load site.
2. Engage the P.T.O.
3. Slowly raise the hoist while letting the cable out until the back of the container is touching the ground.
4. Let the rest of the cable out.
5. Pull the truck slowly forward allowing the rest of the container slide to the ground.
6. Unhook the rectangular end from the container hook.
7. Lower the hoist.
8. Hook the rectangular cable end onto the trailer's holding hook.
9. Pull the cable in.
10. Disengage the P.T.O.

Replacement Parts

Ordering Replacement Parts

To order parts for your unit, please refer to the assembly drawings and the parts breakdown tables in this section for the proper part name. If you would like to speed up your ordering process please visit our online parts store at <http://www.ghmfg.com> and click on the Part Department. Also, please have the following information handy when you log on, call, or write to place your order:

- Your purchase order number.
- Your complete invoicing and shipping address.
- Your required method of shipment (if you do not specify a method, the least costly method will be used).
- Your correct part number, name, description, and quantity needed.
- Your equipments model and serial number for which you are ordering the part.

This chapter contains diagrams and parts breakdown tables for the following assemblies and options:

Ordering Replacement Parts	3-1
Hoist Frame Assembly	3-3
Hoist Frame Assembly Diagram	3-4
Main Frame Weldment (36 in. Kingpin)	3-5
Main Frame Weldment (36 in. Kingpin) Diagram.....	3-6
Poly Fender Installation	3-7
Poly Fender Installation Diagram.....	3-8
ICC Bumper Installation.....	3-9
ICC Bumper Installation Diagram	3-10
Adjustable Idler Sheave Assembly	3-11
Adjustable Idler Sheave Assembly Diagram.....	3-12
LED Light Assembly	3-13
LED Light Assembly Diagram.....	3-14
TBX50LR Final Assembly & Diagram.....	3-15


Landing Gear Installation and Diagram	3-17
Gooseneck Idler Sheave Mount and Diagram	3-18
TBX50L Suspension Installation and Diagram	3-19
Main Valve Bracket Assembly	3-21
Main Valve Bracket Assembly Diagram.....	3-22
Trailer Winch Installation	3-23
Trailer Winch Installation Diagram.....	3-24
Electrical Winch Installation (TBX 52) and Diagram	3-25
Drop-in Stops Installation and Diagram	3-26
Trailer Hydraulic Installation (W/O Rings) TBX50L.....	3-27
Trailer Hydraulic Installation (W/O Rings) TBX50L Diagram	3-29
Transfer Cable Assembly and Diagram.....	3-30

Hoist Frame Assembly

The Hoist Frame Assembly consists of the following parts:

Item #	Part #	Description	Qty.
1	A5231	TBX50 Hoist Frame Without Rings	1
2	A4778	TBX50 Rear Roller Assembly	1
3	A1423	Horizontal Sheave Pin	3
4	A1424	Guide Roller Pin	1
5	A1425	Cable Cylinder Pin	2
6	A1426	Sheave Slide Assembly	2
7	A1636	Cylinder Anchor	2
8	A3931	Vertical Sheave Pin	1
9	A4964	Hoist Frame Weldment	1
10	A4809	Electrical Winch Installation	1
11	D10454	Guide Roller	1
12	D12118	Spacer	2
13	D20756	Collar Rear Roller	2
14	F1016	Bolt 3/8 in. X 3 1/2 in. GR 5	20
17	F1074	Locknut 3/8 in. GR 5	20
15	F1028	Bolt 1/2 in. X 1 1/2 in. GR 5	1
16	F1069	Lock Washer 1/2 in.	1
18	H4370	Cylinder Cable	2
19	M1018	Cotter Pin	2
20	M1201	Cable Assembly	1
21	M1009	Cable End Fitting With Swivel Eye	1
22	M1845	Side Roller	14
23	F1054	Bolt 3/4 in. X 4 1/2 in. GR 5	2
24	F1080	Locknut 3/4 in. GR 5	2
25	M1023	Grease Fitting	22
26	M1008	Cable Clamp	4
27	M1531	Sheave	3
28	D10296	Set Collar	17
29	D20810	Cable Tray Front	1
30	D20811	Cable Tray Rear	1
31	D20820	Bar	1
32	D20821	Winch Cover	1
33	F1001	Bolt 1/4 in. X 3/4 in. GR 5	8
34	F1065	Lock Washer 1/4 in.	8

Hoist Frame Assembly Diagram




Main Frame Weldment (36 in. Kingpin)

The Main Frame Weldment consists of the following parts:

Item #	Part #	Description	Qty
1	A4945	Main Beam Weldment Right	1
2	A4946	Main Beam Weldment Left	1
3	A3754	Light Bumper Guard Weldment	1
4	D21249	Rear Cross Beam	6
5	D21265	Middle Beam	4
6	D21266	Rear Cross Member	2
7	D12124	Pivot Tube	1
8	D21270	Pivot Plate	2
9	D21267	King Pin Cross Member	3
10	D21268	Rear Plate	1
11	D21269	Cross Member Plate King Pin	1
12	D18113	King Pin Plate	1
13	D20832	Guide	2
14	D19401	Vehicle ID Bracket	1
15	D17156	Fifth Wheel Plate Brace	1
16	M1219	King Pin	1

Main Frame Weldment (36 in. Kingpin) Diagram




Poly Fender Installation

The Fender Installation consists of the following parts:

Item #	Part #	Description	Qty
1	A1520	Right Rear Bracket	3
2	A1521	Left Rear Bracket	3
3	M2024	Fender 24 in. Ploy Full	4
4	D12128	Fender End Bar	2
5	D15973	Mud Flap Plate	4
6	D10466	Mud Flap Bracket	2
7	D20738	Gusset	2
8	D18514	Mounting Plate	6
9	D18163	Support Fender Brace	6
10	F1011	Bolt 3/8 in. X 1 3/4 in. GR 5	16
11	F1074	Lock Nut 3/8 in. GR 5	56
12	F1009	Bolt 3/8 in. X 1 1/4 in. GR 5	16
13	F1030	Flat Washer 3/8 in.	64
14	F1010	Bolt 3/8 in. X 1 1/2 in. GR 5	16
15	M1035	Mud Flap Set	2
16	D17624	Bracket Poly Fender	8
17	F1112	Bolt 3/8 in. X 1 in. GR 5	32

Poly Fender Installation Diagram





ICC Bumper Installation

The ICC Bumper Installation consists of the following parts:

Item #	Part #	Description	Qty
1	A5132	TBX50L BUMPER WELDMENT	
2	D21362	HANGER BRACKET	1
3	D21360	SIDE PLATE	4
4	D21366	PLATE INSIDE BUMPER	2
5	D21835	GUSSET SUPPORT	4
6	D21363	TBX50LR ICC BUMPER STOP	2
7	D21361	TOP PLATE	2
8	D21364	GUSSET BUMPER	8
9	D21369	COLLAR PIN	2
10	D12530	CYLINDER PIN	2
11	F1064	WASHER	2
12	F1125	BOLT	2
13	F1217	LOCKNUT	2
14	P1345	BIMBA CYLINDER	1
15	P1341	PIVOT BRACKET	2
16	P1343	BIMBA ROD CLEVIS	1
17	D21399	DOCK BUMPER	2
18	F1408	BOLT	4
19	F1074	LOCKNUT	8
20	D21756	BAR, PAD RETAINER	2
21	D12252	PAD. 8000 BUMPER	2
22	F1195	BOLT	4
23	D12253	BAR 8000 PAD RETAINER	2

ICC Bumper Installation Diagram



DETAIL A




Adjustable Idler Sheave Assembly

The Adjustable Idler Sheave Assembly consists of the following parts:

Item #	Part #	Description	Qty
1	D21323	Tube Idler Arm	1
2	D18430	Pin	1
3	D21272	Tube	1
4	D18431	Collar	2
5	D18432	Bar	2
6	D18396	Cap	2
7	D13563	Gusset	2
8	D13682	Gusset	1
9	D19405	Adjustment Plate	1
10	D19528	Gusset	1
11	M1588	Sheave	2
12	F1013	Bolt 3/8 in. X 2 3/4 in. GR 5	2
13	F1074	Locknut 3/8 in.	2
14	D19404	Sheave Pin	1
15	F1248	Locknut 1 1/2 in. GR 5	1
16	F1425	Flat Washer 1 1/2 in.	1
17	D21132	Adjuster Plate	1
18	F1040	Bolt 1/2 in. X 6 GR 5	1
19	F1076	Locknut 1/2 in. GR 5	1
20	F1061	Flat Washer 1/2 in.	1

Adjustable Idler Sheave Assembly Diagram

WELD NOTE:
ALL WELDS 1/4"
FILLET, UNLESS
OTHERWISE NOTED.




LED Light Assembly

The Light Assembly consists of the following parts:

Item #	Part #	Description	Qty
1	E1386	Side Marker Harness	1
2	E1387	Side Marker Harness	1
3	E1114	Harness License Plate Lamp and ID	1
4	E1115	Harness Right Mid Turn And Mid Clearance	1
5	E1116	Harness Left Mid Turn And Mid Clearance	1
6	E1413	LED Light Kit SUPER 44 4" LIGHT (TRUCK-LITE)	4
7	E1416	LED LIGHT KIT 4" MID-TURN LIGHT KIT	2
8	E1415	LID LIGHT KIT 10050Y LMP MDL 10-LED	2
9			
10	E1401	LED LIGHT LED CLEARANCE LIGHT	5
11	E1122	GROMMET MODEL 10 #10700	5
12	E1123	Light License	1
13	E1124	Plug Compound 2 oz. Tube	1
14	E1127	Junction Box	1
15	E1129	Fitting Compress	4
16	E1023	Pigtail	2
17	E1162	Wire Electrical	15
18	E1107	Split Loom	16
19	E1002	Socket	1
20	E1043	Wire Electrical	1
21			
22	E1062	7 Way Wire	65 ft.
23	F1001	Bolt 1/4 in. X 3/4 in. GR 5	2
24	F1059	Flat Washer 1/4 in.	2
25	F1087	Locknut GR 5	12
26	F1210	Screw Machine	12
27	D18441	Terminal Mount	1

LED Light Assembly Diagram




TBX50LR Final Assembly & Diagram

The TBX50LR Final Assembly consists of the following parts:

Item #	Part #	Description	Qty
1	A4947	TBX50L Main Frame Weldment – 36 Kingpin	1
2	A4204	Landing Gear Installation	1
3	A1507	Hinge Pin Assembly Standard	1
4	A3235	Ratchet Tie Down Hook and Strap	8
5	A3318	Ratchet Tie Down Assembly	8
6	A3534	Ratchet Tie Down Installation	1
7	A3443	Mid Turn Bracket Assembly	2
8	A4201	Decal Installation	1
9	A3745	Safety Prop Inst	1
10	A4758	Poly Fender Inst	1
11	A4231	Reflective Tape Installation	1
12	A4962	TVX50L Suspension Inst	1
13	A3756	Ladder Weldment and Inst	1
14	A3757	Safety Prop Tube Stop	1
15	A4869	Cylinder Lift	2
16	A4955	Idler Sheave Assembly and Inst	1
17	A4129	TBX50 Frame Hydraulic Install	1
18	A4954	Valve Bracket Installation	1
19	A3924	TBX Light Installation	1
20			
21	A4957	Gooseneck Idler Sheave Mount	1
22	A4965	TBX50LR Hoist Frame Assembly - I-Beam	1
23	A4956	TBX Lower Cylinder Mount	1
24	A3930	Single Winch Installation	1
25	A3932	Transfer Cable Assembly	1
26	A4093	Drop-In Stop	2
27	A5133	TBX50L ICC Folding Bumper Installation	1
28	A4754	Gooseneck Fender Installation – Poly	1
30	D10296	Set Collar	12
31	D12120	Hinge Head Retainer	1
32	D12123	Rear Hinge Collar	1
33	D12139	Cylinder Pin Collar	4

34	D12642	Handle	1
35	D18230	Hinge Plate	2
36	D18366	Hinge Tube	1
37			
38			
39	F1016	Bolt	12
40	F1039	Bolt	4
41	F1049	Bolt	1
42	F1074	Locknut	12
43	F1076	Locknut	4
44	F1078	Mounting Bracket Right	1
45	M1845	Side Roller Assembly	12
46	M1023	Grease Fitting	35
47			
48			
49	D20824	S/N Plate	1




Landing Gear Installation and Diagram

The Landing Gear Installation consists of the following parts:

Item #	Part #	Description	Qty
1	M1217	Landing Gear Set	1
2	M1473	Adjustable Brace	4
3	D19403	Bracket	4
4	F1044	Bolt 5/8 in. NC X 2 GR 5	24
5	F1078	Locknut 5/8 in. NC GR. 5	24
6	D18183	Landing Gear Mount Angle With Notch	1
7	D18184	Landing Gear Mount Angle	3


A4204



Gooseneck Idler Sheave Mount and Diagram

The Gooseneck Idler Sheave mount consists of the following parts:

Item #	Part #	Description	Qty
1	108485	Sheave Plate	2
2	D18490	Front Plate (Left)	1
3	D18498	Front Plate (Right)	1
4	D18486	Collar Pin Support	1
5	D18487	Collar	1
6	D21276	Support Bar	1
7	D18494	Plate Cover	1
8	D18495	Plate Strap	1
9	D18517	TBX Front Stop	2
10	M1588	Sheave, 4-7/8" Diameter	1
11	D19295	Sheave Pin	1
12	F1013	Bolt	1
13	F1074	Locknut	1




TBX50L Suspension Installation and Diagram

The Suspension Installation consists of the following parts:

Item #	Part #	Description	Qty
1	M1489	Suspension	2
2	M2038	Suspension	1
3	P1348	Valve 4 Way	1
4	D20733	Bracket	4
5	D20734	Bottom Bar	4
6	D20735	Bar	4
7	D18157	Bulkhead Plate	1
8	D18158	Air Tank Holder	4
9	D19316	Gusset	4
10	P1302	Tank Tandem Included in this kit	1
11	P1046	Fitting NTA	
12	P1098	Fitting NTA	
13	P1029	Glad Hand Blue	
14	P1030	Glad Hand Red	
15	P1050	Adapter Bulk Head	
16	P1043	Fitting NTA	9
17	P1329	Push And Pull Valve	1
18	P1037	Air Control Dump Kit	1
19	P1001	Fitting NTA	22
20	M1840	Leveling Valve	1
21	P1068	Pilot Valve	1
22	M1902	ABS Dedicated	1
23	D18159	Pilot Bracket	1
24	P1083	Valve Pressure, Protect	1
25	P1034	Tubing Nylon (By the foot)	40'
26	P1033	Tubing Nylon (By the foot)	50'
27	P1079	Air Fitting	8
28	H2186	Coupling	4
29	D20736	Filler Bar	4
30	P1328	Check Valve	1
31	D21094	Gusset	4
34	P1344	3 Way Valve	1
35	D21767	Valve Bracket	1
37	M1242	Tubeless Tire 11R22.5	8
38	M1783	Wheel	8

39	M1088	Valve Stem	8
40	M1214	Axle Assembly	2




Main Valve Bracket Assembly

The Main Valve Bracket Assembly consists of the following parts:

Item #	Part #	Description	Qty
1	D15077	Mounting Bracket Right	1
2	D15078	Mounting Bracket Left	1
3	D21271	Gusset	2
4	D19444	Cover Plate	1
5	D13796	Tab	6
6	D18571	Air Valve Mount	1
7			
8	D16904	Handle Holder	1
9	F1017	Bolt 3/8 in. X 4 in. GR 5	3
10	F1074	Locknut 3/8 in. GR 5	3
11	F1260	Machine Screw	4
12	F1087	Locknut GR 5	4
13	F1001	Bolt 1/4 in. X 3/4 in.	6
14	F1217	Locknut 1/4 in. GR 5	10
15	F1121	Bolt 1/4 in. X 2 in. GR 5	4

Main Valve Bracket Assembly Diagram




Trailer Winch Installation

The Single Winch Installation consists of the following parts:

Item #	Part #	Description	Qty
1	D19437	Support Bar	3
2		Mount Angle Front (Included with winch)	1
3		Mount Angle Back (Included with winch)	1
4	D19440	Right Spacer Bar	2
5	D19441	Left Spacer Bar	2
6	M1803	Tulsa Winch	1
7	F1044	Bolt 5/8 in. X 2 in. GR 5	8
8	F1078	Locknut 5/8 in. GR 5	8
9	A4284	Screw Drum Assembly	1
10	D19639	Drum Tube	1
11	D19640	Bar	1
12	D20771	Cable Block	2
13	F1205	Set Screw 3/8 in. X 1/2 in.	4
14	D20779	Spacer Winch	1
15	D20788	Spacer	1
16	D21133	Support Angle	

Trailer Winch Installation Diagram


Single Winch



Electrical Winch Installation (TBX 52) and Diagram

The Electrical Winch Installation consists of the following parts:



Item #	Part #	Description	Qty
1	E1391	Superwinch	1
2	E1049	Junction Box	1
3	E1378	Single Pin Receptacle	1
4	E1379	Single Pin Plug	1
5	E1392	Loom	50'
6		6 Gauge Black Wire	50'
7	E1174	Clamp Strap	4
8	F1001	Bolt	6
9	F1217	Locknut	6
10	F1011	Bolt	2
11	F1074	Locknut	2
12	F1060	Flat Washer	2



Drop-in Stops Installation and Diagram

The Drop-in Stops Installation consists of the following parts:

Item #	Part #	Description	Qty
	D19172	Hook Front Stop	1
	D18461	Hook Rest	2




Trailer Hydraulic Installation (W/O Rings) TBX50L

The Trailer Hydraulic Installation consists of the following parts:

Item #	Part #	Description	Qty
1	D18531	Clamp Bracket	2
2	D18531	Angle	1
3	D21098	Nipple	1
4	D21062	Nipple	1
5	D19460	Nipple	1
6	D21097	Nipple	1
7	D21097	Nipple	1
8	D19462	Nipple	1
9			
10	D19463	Nipple	2
11	D16921	Nipple	2
12	D19466	Nipple	4
13	D21901	Modified Male Adapter	1
14	D19482	Modified Hollow Hex Plug	1
15	H1391	Hose	1
16	H2691	Hose	1
17	H3344	Hose	1
18	H1119	Hose	4
19	H1607	Hose	2
20	H3882	Hose	2
21	H3883	Hose	2
22	H1134	Hose	1
23	H1133	Hose	1
24	H1132	Hose	1
25	H1402	Hose	1
26	H1393	Hose	2
27	H2815	Hose	1
28			
29	H3857	Fitting	4
30	H2153	Fitting	2
31	H3858	Fitting	2
32	H1064	Fitting	11


33	H1082	Fitting	2
34	H1262	Fitting	2
35	H2819	Fitting	2
36	H3430	Fitting	1
37	H1067	Fitting	1
38	H1051	Fitting	1
39	H2366	Fitting	1
40	H1066	Fitting	6
41	H1009	Coupling	2
42	H1005	Coupling	2
43	H1319	Fitting	1
44		Valve	1
45	H3845	Crossover Relief Valve	1
46	H1027	Elbow 45 Degree	4
47	H1192	Tee	2
48	M1010	Clamp, Stauff	2
49	M1585	Clamp. Stauff	7
50	M1579	Clamp, Stauff	5
51	M1586	Clamp, Stauff	5
52	H1006	Coupling	1
53	H2261	Bushing	1
54	H2260	Bushing	1
55	D20745	Clamp Bracket	6
56	H1057	Fitting	4
57	D20746	Crossover Bracket	1
59	F1131	Bolt	2
60	F1072	Locknut	2
61	H3206	Fitting	1
62	H2108	Fitting	1

Trailer Hydraulic Installation (W/O Rings) TBX50L Diagram



Transfer Cable Assembly and Diagram

Item #	Part #	Description	Qty.
1	M1594	Cable	1
2	M1595	Chain	1
3	M1597	Master Ring	1
4	M1596	Coupler	1



Appendix: Maintenance

A

Introduction

For years of trouble-free service, it is important to properly maintain your equipment. Failure to do so could be costly and may void your Manufacturer's warranty. This appendix will help you to maintain your TBX-Two Box Trailer by providing a regular maintenance checklist, troubleshooting guide, diagrams, and schematics for its maintenance.

The following regular maintenance checklist, troubleshooting guide, diagrams, and schematics are located within this appendix:

Introduction	A-1
Maintenance and Lubrication Checklist	A-2
Hydraulic Hose Assembly Maintenance	A-3
Hydraulic System Information	A-3
Troubleshooting	A-3

Maintenance and Lubrication Checklist

The following are the minimum maintenance recommendations:

Each Day

Inspect the cable for:

- Broken wires.
- Severe twists or kinks.
- Crushing of the cables.

Inspect the sheave for:

- Excessive wear or damage.
- Cable to run straight off the sheaves.

Inspect the drum to make sure the cable is rolling on evenly with no crossing of the cable.

Inspect all hardware on the cable for excessive wear or damage.

Inspect the cable on the Electric Hoist Cable Winch for:

- Broken wires.
- Severe twists or kinks.
- Crushing of the cable.

Inspect all hardware on the cable for the Electric Hoist Cable Winch for excessive wear or damage.

Replace or repair any part that is in need of repair.

Each Week

Lubricate grease points.

- Rollers
- Sheaves
- Rear Hinge
- Lift Cylinders

For Stinger

Lubricate the two extra Rear Rollers on the stinger attachment..

For Dead Lifts

Lubricate the Rear Center Sheave and two extra Rear Rollers.

Every Two (2) Months After

Inspect oil for any discoloration:

- Milky color indicates water or condensate.
- Darkened color indicates oxidation or dirt.

Listen carefully for any abnormal pump noise.

Hydraulic Hose Assembly Maintenance

Inspect the hydraulic hose assembly every 400-600 hours or every three months depending on the following factors:

- Critical Nature of Equipment
- Operating Temperatures
- Operating Pressures
- Environmental Factors
- Type of Usage (rugged, abusive, shock, vibration, operating time)
- Accessibility of Equipment

Pay closer attention to high heat source areas, tight abrasion areas, and routing. These areas may need their hoses to be replaced more often.

Caution: Before inspecting your hydraulic hose assembly be aware of the following safety precautions.

- **Pressure** - Hydraulic fluid under pressure is dangerous and can cause serious injury. Never touch a pressurized hydraulic hose assembly with any part of your body. Instead use a piece of cardboard to locate a pressurized leak. If by accident hydraulic fluid should puncture the skin seek immediate medical attention or risk losing the injured body part or death.
- **Temperature** - Hot fluid can cause severe burns.
- **Flammability** - When ignited some hydraulic fluids can explode and/or cause fires.
- **Mechanical** - Hydraulic fluid creates movement, which causes parts of your equipment to move or rotate at high speeds.
- **Electricity** - Electricity can create the spark that causes a fire, explosion, or electrocution. Shut it down.

To Inspect Hydraulic Hose Assemblies:

1. Turn off equipment power. We suggest taking the key, placing it in a safe place, and disconnecting the battery.
2. Place equipment and components in a safe or neutral position. Make sure components are not in mid-stroke, mid-cycle, or holding a load.
3. Inspect hose and fittings for damage or leaks. Pay close attention to the following areas:

Hose Cover

Visually inspect the cover for signs of:

- Abrasion.
- Blisters.
- Nicks, cracks, or cuts.

Squeeze with your hands to test for hardness. Be careful, the hose could be hot.

Leakage

The signs of leakage are :

- Puddles of fluid in or around the equipment.
- Low fluid reservoir.
- Greasy\dirty hose.

Routing

Check to make sure the hoses are not:

- Rubbing against each other.
- Located next to a high heat source.
- Twisting or kinking.

4. Repair or replace as needed.
5. Inspect other hydraulic components. Take the time to inspect valves, pumps, cylinders, and other hydraulic components for leaks and damage.
6. Turn on the power.

If any step in this inspection indicates a problem or even a potential problem, have it checked out and repaired immediately. Also keep a detailed record of all inspection and service information. Use this record to identify problem areas and trends.

Be aware of your equipment. You know your equipment better than anyone else. If you feel something is not right, check it out to avoid the unwanted result of a hose assembly rupture.

Hydraulic System Information

Because the hydraulic oil is in constant contact with precision-machined surfaces, the oil should be kept as clean as possible to prevent unnecessary wear. Dirt particles in the hydraulic oil could cause pump failure. In such instances, the entire hydraulic system must be drained, flushed clean, the filter changed, and the entire system filled with new oil.

Maintain the hydraulic oil level by observing the sight gauge on the reservoir when all cylinders are in the retracted position. The hydraulic oil must be kept between the high and low mark on the sight gauge.

The recommended hydraulic oil for use in this system will meet the following specifications:

Note: All temperatures are in Fahrenheit.

Gravity	31	Pour Maximum Degrees Fahrenheit	
Flash Point Min	360°	Color Max	35
Viscosity	100° to 210°	SAE	2
Fire Min	415°	Carbon Residue – Max %	10
Viscosity 210°	48	Neutral #	0.05
V.I. Min	95	Sulfur	0.02

Note: Oil operating temperatures should not exceed 180° F.

Caution: Use only oil which contains anti-foam and anti-oxidizing additives. Do not use oils with low viscosity, naptha base, aircraft hydraulic oil, or hydraulic brake fluid. Oil with a low pour-point must be used for low temperature operation.

Important Note

Hydraulic System Pressure.....1900 PSI at 1500 RPM

Operating this system in excess of the Manufacturer's recommendations will void warranty

Troubleshooting

Use the following table to help you diagnose and resolve problems with the operation of the unit.

Problem	Probable Cause and/or Solution
Unit operates with jerky motion.	<ul style="list-style-type: none"> • Be sure oil is at the proper level. • Check for possible leaks and repair if necessary. • After any work on the hydraulic system: <ol style="list-style-type: none"> 1) Fill tank with hydraulic oil. 2) Replace filter cartridge. 3) Operate cylinders to remove air from the system.
Oil is cold	<ul style="list-style-type: none"> • Use the following procedure to warm the oil: <ol style="list-style-type: none"> 1) Operate the hoist control to bottom out the cylinder keeping the lever pushed for approximately five (5) minutes to warm up the oil. 2) If the problem reoccurs, check the type of oil being used. It is highly likely that the wrong type of oil is being used.
Air in the System (Oil is a milky color)	<ul style="list-style-type: none"> • Check for a leak in the suction line.
Unit does not lift loaded container	<ul style="list-style-type: none"> • Hydraulic pressure is set too low. Reset the pressure to 1900 PSI with engine at 1500 RPM. If pressure cannot reach 1900 PSI, check pump and replace if necessary. • Hydraulic cylinder may have an internal leak. Determine which cylinder is leaking and repack.
Control problems - hesitation noted	<ul style="list-style-type: none"> • Air is present in the system. Be sure oil is at the proper level. Look for any possible air leaks at hose clamps on the suction hose. • Determine oil type: use only anti-foam hydraulic oil.
Pump is noisy and faltering when lifting load	<ul style="list-style-type: none"> • Possible damage to pump: check and replace if necessary.
Vibrations, particularly at high speed	<ul style="list-style-type: none"> • Suction line is clogged.
Oil leaks noticed	<ul style="list-style-type: none"> • If oil is noticed: <ol style="list-style-type: none"> 1) Change the seal on the pump shaft. 2) Repack the cylinders. 3) Properly tighten fittings. 4) Check hydraulic oil for foaming.
Reservoir is overflowing from top	<ul style="list-style-type: none"> • Reservoir is too full. • Hoist is being lowered without engaging the pump. • Air is present in the system.

Appendix: Optional Features

B

Introduction

This appendix contains information on the TBX-Two Box Trailer's optional feature. The following option is covered:

Introduction	B-1
Electric Hoist Cable Winch	B-2

Electric Hoist Cable Winch

Caution: Pull the free wheel lever up before connecting to the hoist cable or the winch will be damaged during container loading. Remember to push the free wheel lever down to engage the winch before pulling the hoist cable back to the rear.

The electric hoist cable winch pulls the hoist cable to the rear of the hoist for loading containers. The controls for the electric winch are located on the electric winch at the rear of the hoist.

To Use the Electric Cable Winch:

1. Pull the free wheel lever up.
2. Fasten the electric winch cable to the rectangular cable end.
3. Hook the rectangular cable end onto the container hook.
4. Load the container onto the hoist.
5. Unhook the rectangular cable end from the container.
6. Push the free wheel lever down.
7. Turn the black rubber cap on the side of the winch to bring the electric winch cable and hoist cable to the rear of the hoist.